

Getting Started

Requirements

- 'Cleaned up' and 'defragmented' system.
- Deactivate services which are not essentially needed.


e-mix "pro edition"

Installation

1. Do not connect your console to the system until the installation program is asking you to do so.
2. *Installation with the CD-Rom:* Place the CD into the CD-Rom drive and start the installation program.
Installing the Download Version: Double-click the '*.msi' file that you have downloaded from the internet.
3. Follow the instructions of the installation program.
4. Connect the console to your system (USB cable) when the installation program asks you to do so.

Console Ports

- USB port
- Microphone port
- Headphone / Line Out port
- Line In port



First start

How to start the program:

- Double-click with the left mouse button on the desktop program icon.
- Alternatively, select [Programs] [e-mix] [e-mix] in the Start menu.

The very first time you start the program, a window which will activate the software will appear automatically. Enter the number that is printed on the bottom of the console into the text box and click 'Next'.



Note

In order to use the software without the console you need a 'Standalone Activation Key'. You can receive this key by registering online. To register online just click 'Next' and follow the instructions of the registration wizard.

Audio channel settings

When you launch e-mix for the first time, a dialog box is displayed where you can choose your audio settings. We recommend that you use the "KernelStreaming" technology only on systems that support this feature. Otherwise, or if there are any problems when using kernel streaming, select "DirectSound".

It is recommended that you choose the following options on the 'Audio Out' page:

Channel	Driver	Equipment
Master output	DirectSound	e-mix mp1200
Monitor output	DirectSound	PC soundcard